

- Keep out of reach of children or pets. This appliance should not be used by children without supervision.
- Do not cut the cord as this will result in voiding your warranty.
- Care should be taken to arrange the power cord so that it cannot be accidentally tripped over or pulled.
- Do not attempt to repair the light yourself. Return to an authorized service centre or place of purchase if a fault occurs.
- Do not stare/look directly into light while in use.

LIMITED WARRANTY

This PondMAX Pond/Garden Light is warranted to the initial purchaser, to be free of defects in materials and workmanship at the time of initial purchase and for a period of 2 years. In the event this product malfunctions within two years from the date of purchase, the sole obligation of PondMAX International (hereinafter referred to as PondMAX™) will be to repair the unit or replace with an equivalent new or factory refurbished unit at PondMAX's discretion, subject to the following conditions:

- The malfunction is proved attributable to a defect in materials or workmanship, including repairs performed under this warranty. Malfunction for any other reason-including but not limited to misuse, negligence, accident, or tampering with parts, incorrect wiring, or improper installation-will not be remedied under this warranty.
- PondMAX™ specifically does not guarantee chemical compatibility, and expressly does not warrant units from any problems caused by use in liquids other than clean water.
- All warranty repairs must be performed by PondMAX™ or a PondMAX™ authorized company. Purchaser must retain the purchase receipt and present it with this certificate as proof of ownership and entitlement to warranty repairs. Unauthorized repairs will not be compensated by PondMAX™, and are not the responsibility of PondMAX™, and if such repairs damage the product, such damages are not remedied under this warranty.
- Purchaser shall bear all shipping, packing and insurance costs and all other costs, excluding labor and parts necessary to effectuate repairs under this warranty.

- Periodic check-ups are not covered by this warranty.
- This warranty is in lieu of all other express warranties which now or hereafter might otherwise arise with respect to this product. Any and all limited warranties, including the warranties of merchantability and fitness for particular purpose, shall have no greater duration than the duration period of the express written warranty applicable to this product, and shall terminate automatically the expiration of such duration period. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. No action shall be brought for breach of any implied or express warranty after one year subsequent to the expiration of the duration period of the express written warranty.
- Incidental and consequential damages caused by malfunction, defect, or otherwise, and with respect to breach of any express or implied warranty, are not the responsibility of PondMAX™, and, to the extent permitted by law, are hereby excluded for property damage, loss of livestock and, to the extent not unconscionable, for personal injury damage. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
- This warranty does not apply to any malfunction arising out of any application of this product other than normal use, unless such application is upon request specifically approved in writing by PondMAX™.
- The provisions of this warranty are severable and if any provision shall be deemed invalid, the remaining provisions shall remain in full force and effect.
- Rights under this warranty are not assignable without the express prior consent in writing by PondMAX™ and, regardless of the terms of such consent in writing, such assignee shall have no greater rights than his assignor had against PondMAX™.

The Warranty is given by PondMax International, P.O. Box 341, San Leandro, CA 94577; contactable by phone (toll free 888.868.1185) or email (info@pondmax.com).

E. & O. E.



- ULTRA SERIES - HALOGEN POND LIGHT



INSTRUCTION MANUAL

PondMax International

P.O. Box 341, San Leandro, CA 94577

Toll Free 888.868.1185

email: info@pondmax.com

PondMAX

- ULTRA SERIES - HALOGEN POND LIGHT

HALOGEN LIGHT	
POWER CONSUMPTION - SMALL LIGHT (24PL000)	10 Watts / 12-16 Volts AC
POWER CONSUMPTION - LARGE LIGHT (24PL002)	20 Watts / 12-16 Volts AC
CABLE LENGTH	16 FT (With Starter Light) 9 FT (With Add-On Light)

Thank you for purchasing a PondMAX product!

DESCRIPTION AND FEATURES

Your PondMAX Halogen Pond Light has been manufactured with advanced technology and quality materials to ideally integrate into most ponds thanks to their compact design.

- The PondMAX light has a glass lens and is suitable for submersible use only.
- A 115 volt transformer (not included) converts the power supply to a safe 12 volts for peace of mind in your pond or garden (Transformers sold separately).

INSTALLATION AND OPERATION

- If required, have a qualified electrician install a weather proof power point near to the pond garden, within reach of the transformer and light.
- Mount the transformer in a dry and protected location making sure that it will not get wet by either rain or an irrigation system.
- For pond installation slide the weighted base into the circular recess on the bottom of the light body. Position the light in the desired location taking care to keep the female plug dry, at the end of the cable.

- Adjust the light until facing in the general direction of the feature you wish to illuminate. We recommend final adjustments be carried out at night.
- For single light installations plug the female plug on the end of the light cable into the male connection on the Transformer Cable (5) and then the free end into the transformer, tightening both locking collars firmly. The transformer can now be turned on.
- Once in the correct position, lock the light by tightening the thumb screws, taking care not to over tighten.
- Multiple lights can be connected together to the same transformer using the Add-On Light Connector (4) on the side of the light body. Transformer wattage requirement is dependent on the number of lights that are added.

MAINTENANCE

There is minimal maintenance required on the PondMAX Halogen pond lights. The light should be inspected on a regular basis to ensure the light or cable is not damaged in any way. Clean the lens on the light regularly for maximum efficiency.

IMPORTANT SAFEGUARDS

To guard against injury, basic safety precautions should be observed including but not limited to the following;

- The light should only be used in clean water. Do not use the light in any solvent or flammable liquids. Do not use in chlorinated or salt water.
- The light should never be used outside of water. For submersible use only.
- Do not operate the light if the light or any of the components of the light such as the power cable or transformer have been damaged.
- If the 115V plug supplying the transformer gets wet, do not unplug the cord. Disconnect the circuit breaker that supplies power to the power outlet.
- Always use a properly grounded power supply that is connected to a Ground Fault Circuit Interrupter (GFCI)
- Always unplug the light from the power supply when not in use or before performing any maintenance. Never pull the transformer cord to disconnect the plug from the power supply. Grasp the plug and pull to disconnect.
- Do not operate light in water temperatures exceeding 95°F, or colder than 40°F.

