

HOW TO USE THE DIELECTRIC GREASE FOR EXTRA MOISTURE PROTECTION WHEN DAISY CHAINING LIGHTS TOGETHER:



1 Inside the light box, you will find a tube of dielectric grease



2 Remove the cap and open the protector seal



3 Remove the cover for the daisy chain socket



4 Put a small amount of grease on the middle pin in the daisy chain socket



5 Align the plug with the middle pin and insert gently



6 Tighten down to hold the plug with the socket



info@pondmax.com
888.868.1185